



5123 N.LOOP 1604 west
Suite #104
San Antonio, TX. 78249

(210) 408-8019
(FAX)(210) 479-2330

EZ DIGITAL TIMER INSTRUCTIONS

PLEASE READ ALL INSTRUCTIONS BEFORE ATTEMPTING TO SET THE CLOCK

- 1) **CONNECTING UNIT.** Connect the unit to a 6V or 12V battery and the feeder motor. Check the fuse in the fuse holder. Current battery charge level and type will be displayed on the screen.
- 2) **CLOCK SETUP.** Press the ▼ button or program button once from "READY" mode to enter the "CLOCK" mode. Press the program button again to enter clock settings. Use the + or - buttons to adjust to the desired week, then press program and use the + or - buttons to adjust hour, then press program and use the + or - buttons to adjust minutes. After the time is set wait for 10 seconds to go back to "READY" mode automatically.
- 3) **SETTING THE FEED TIME, RUN TIME & RPM.** Use the ▲ or ▼ buttons from "READY" mode to enter the appropriate Feeding (FEED.1 thru . 8). Press the program button to enter the feed time and use the instructions above (Item #2) to enter the appropriate time or "OFF" position. Press the program button again and use the + or - button to set the run time duration (0 to 30 seconds per feed time). Press the program button again and use the ▲ to ▼ buttons to set the RPM/Motor speed. Press the program button again and use the ▲ to ▼ buttons to enter the next Feeding. After set, wait 10 seconds to go back to "READY" mode automatically.
- 4) **TESTING UNIT.** To test the unit, press and release the "TEST" button. The unit will turn on after a 10 second delay giving the user a chance to STEP BACK. The test will run with a duration set by the first feed time.
- 5) **CHECK BATTERY CHARGE.** The battery level, indicated by the 5-bar icon on the screen, will display the charge level in real-time

WARRANTY: 2 year warranty from the date of purchase against manufacture defects due to normal wear and designed usage. To return defective timers please send just the timer to the following address plus a check or money order in the amount of \$10 for return postage and handling. Also please send purchase information.

SEND TO: Spreader Technology L.P.
North Loop 1604 West #104
San Antonio, Texas 78249