

**SpinTech Outdoor Products
5123 North Loop 1604 West
Suite #105
San Antonio, Texas 78249
TEL: 210-408-8019
Fax: 210-479-2330**

Installation Instructions for 6 volt LED Hog Light.

Model #HL-6/12V

- 1. Remove the lower plastic housing cover from the timer and remove the rubber plug from the bottom.**
- 2. Remove wiring from LED Hog Light . Connect the pigtails to the correct 6 volt battery terminals. (Red wire is positive and Black wire is negative)**
- 3. Attach the alligator clips from the timer to the top of the pigtails (Black alligator clip to black wire and Red alligator clip to red wire).**
- 4. Take the remaining alligator clip (white wire) and attach it to the blue positive wire terminal on the 6 volt motor.**
- 5. Take the remaining modular plug and insert it through the 7/16" hole provided in bottom of cover. Plug modular plug into receiver on LED Hog Light. Then replace cover back over timer. Place LED Hog Light on bottom of unit and screw down tight.**

Note: LED Hog Light will only come on when the feeder is activated and will then remain on for 30 minutes and then automatically go off.